



Starter Kit and User Manual for the HelloDevice 1300

Version 1.1

Starter Kit and User Manual for the HelloDevice 1300

Version 1.0

Last revised on July 16, 2000-07-16

Printed in Korea

Copyright

Copyright 2000, Sena Technologies, Inc. All rights reserved.

Sena Technologies reserves the right to make changes and improvements to its product without providing notice.

Trademark

HelloDevice™ is a trademark of Sena Technologies, Inc.

Windows® is a registered trademark of Microsoft Corporation.

Ethernet® is a registered trademark of XEROX Corporation.

Notice to Users

When a system failure may cause serious consequences, protecting life and property against such consequences with a backup system or safety device is essential. The user agrees that protection against consequences resulting from system failure is the user's responsibility.

This device is not approved for life-support or medical systems.

Changes or modifications to this device not explicitly approved by Sena Technologies will void the user's authority to operate this device.

Company Address

Sena Technologies, Inc.

210 Yangjae-dong, Seocho-gu

Seoul, Korea 137-130

Telephone: +82-2-573-7772

Fax: +82-2-573-7710

Email: info@sena.com

Website: <http://www.sena.com>

Table of Contents

1. Before You Start

2. Overview

3. Main Board Specifications

3.1. Power Supply

3.2. Microprocessor

3.3. Ethernet Interface

3.4. Serial Communication Interface

3.5. Flash Memory

3.6. Firmware

4. Setting Up the Hardware

4.1. Installing Utility Software

4.2. Connecting Hardware

4.3. Configuring Network

5. Quick Tour

5.1. Building a Homepage

5.2. Serial Communication Demo Using Terminal Applet

6. Connecting User Devices

6.1. Connecting Hardware

6.2. Sample programs

Appendix A. IP address configuration by using cross-over Ethernet cable

1. Before You Start.

- **Items supplied in the HelloDevice 1300 Starter Kit**

Items		Piece(s)
Hardware	HelloDevice 1300 Main Board	1
	5V Switching Mode Power Supply (SMPS) or Power Adaptor	1
	DSUB Cable for RS232 Communication	1
Software	HelloDevice Utility Software and Sample Demo Program (Download the latest version at http://www.sena.com/download)	1
User's Manual		1

- **Operating Environment**

- Voltage Supply = 5V DC \pm 10%
- Current Supply = 200mA or lower
- Operating Humidity = 0 ~ 95%
- Operating Temperature = 0 ~ 50 Degrees Centigrade

- **Technical Support**

Sena Technologies, Inc.

210 Yangjae-dong, Seocho-gu, Seoul, Korea 137-130

Phone: (+82-2) 573-7772

Fax: (+82-2) 573-7710

Email: support@sena.com

<http://www.sena.com>

2. Overview

The HelloDevice is a connectivity solution that allows any device in any industry to communicate over any network, using any interface. The HelloDevice 1x00 product family is a board-level Ethernet controller that lets manufacturers and system integrators connect devices such as home appliances and industrial control systems directly to the Internet via Ethernet, and remotely communicate with and control them with standard web browsers such as Microsoft Explore and Netscape Navigator. The HelloDevice 1x00 product family is categorized into three types depending on how the HelloDevice connects to a user device:

- Digital I/O communication module (HelloDevice 1100)
- Dual-port RAM communication module (HelloDevice 1200)
- Serial communication module (HelloDevice 1300)

Table 2.1 shows the basic specifications of the HelloDevice 1x00 Series.

Model Basic Spec.	HelloDevice 1100	HelloDevice 1200	HelloDevice 1300
CPU	Scenix Sx52BD (8 bits microprocessor, 50 MIPS)		
Memory	512 Kb flash memory (Saves user Web files)		
Network Connection	10 Base-T Ethernet Interface (IEEE802.3)		
Connection to the User device	16 contact points digital input 16 contact points digital output	2 KB dual port RAM	1 channel RS-232/485 Max. 38,400 bps
Internet Protocol Support	HTTP ¹ / SMTP / BOOTP		
	TCP / UDP		
	IP / ICMP / ARP		
	Ethernet (IEEE802.3)		
Utility Software	HelloDevice utility software (for Windows 95/98/NT/2000 platform) : IP addressing and Web page uploading		

Table 2.1 Basic specifications of the HelloDevice 1x00

¹ Currently, HTTP 1.1 specifications are supported.

3. Main Board Specifications

The hardware configuration and the system block diagram of the HelloDevice 1300 Main Board are shown below in Figure 3.1 and Figure 3.2. (The board layout in Figure 3.1 may be slightly different from the layout of the HelloDevice main board in the Starter Kit for the performance improvement.)




Figure 3.1. the HelloDevice 1300 Configuration and Components




Figure 3.2. the HelloDevice 1300 System Block Diagram

3.1 Power Supply

- Voltage supply = 5V DC \pm 10%
- Current supply = 200mA or lower

3.2 Microprocessor Specifications

- Scenix SX52BD 8 Bit Microprocessor
- 4 KByte Program Memory
- 52-pin PQFP (See Figure 3.1, Part [2])

3.3 Ethernet Interface

The HelloDevice is connected to an Ethernet hub or switch by the RJ45 connector on the Main Board. Distances of up to 100m are supported.

3.3.1 Ethernet Controller

The Ethernet Controller provides the functions of framing and addressing data, and detecting and avoiding errors and collisions (See Figure 3.1, Part [3-1]).

3.3.2 Specifications

- RealTek Full-duplex Ethernet Controller: RTL8019AS
- Supports 10 base-5, 10 base-2 and 10 base-T compliant with IEEE802.3
- 16 KByte SRAM
- NE2000 Compatible

3.3.3 RJ45 Connector

- Shielded Connector compliant with AT&T258 specifications (See Figure 3.1, Part [3-2])




Figure 3.3. RJ45 connector

3.3.4 Status Indicator LED's


There are four status indicator LED's which indicate the following: (See Figure 3.1, Part [3-3]).

- **Power LED**
Indicates the Power-On status of the HelloDevice.
- **Rx LED**
Indicates that the Ethernet controller is receiving Ethernet packets from the network. If it is correctly connected to the network, this LED will blink when packets are received
- **Tx LED**
Indicates that the Ethernet controller is sending packets. Before setting the HelloDevice network configuration, this LED will blink every second. After network configuration, if connected correctly, this LED blinks only in response to requests from the user's PC, for example ping or server activity.
- **Collision LED**
Indicates that one or more Ethernet packets transmitted from the Ethernet controller to the network may have collided with another packets. In this case, the Ethernet controller will automatically resend the packets.

3.4 Serial Communication Interface

- RS232/485 communication mode switching by sliding switch
- DB9 connector for RS232/RS485 communication
- 150 ~ 38400 baud rate

Pin assignment of 9-pin DSUB connector is shown in Figure 3.4. All the signal lines for RS232 and RS485 communication are included in the HelloDevice serial port. Communication mode is switched by using RS232/485 conversion switch, which is represented as SW2 in the main board.



Pin No.	Symbol	Description	Function
1	RS485+	RX485+	485 data line
2	RxD	Receive Data	Data Input
3	TxD	Send Data	Data Output
4	RS485-	RX485-	485 data line
5	GND	Signal Ground	-
6	NC	Not connected	-
7	RTS	Ready To Send	Handshake Output (+12V=Ready to Rx, -12V=Not Ready to Rx)
8	CTS	Clear To Send	Data sent
9	NC	Not connected	Data sent only at +3V ~ 12V

Figure 3.4. Pin Assignment of the HelloDevice DSUB Connector

3.5 Flash Memory

Web page resources files that the user creates to control the user device are stored in the flash memory of HelloDevice Main Board.

- 4 MBits (512 KBytes)
- Composed of 2,048 sectors of 256 Bytes.

3.6 Firmware

The HelloDevice Firmware resides in the program memory of microprocessor. The firmware includes a TCP/IP stack conforming to the Open System Interconnection (OSI) requirements for an Internet connection, and the serial communications interface for connection to the user device.

Layer		The HelloDevice Support				
7	Application	HTTP	Serial Communication. Interface	System Management	BOOTP	
6	Presentation					
5	Session					
4	Transport					
3	Network	TCP		UDP		
2	Data link	IP / ICMP				ARP
1	Physical layer	Ethernet (IEEE802.3)				

Table 3.1. OSI 7 Layers and the HelloDevice 1300 Firmware

4. Setting Up the Hardware

The HelloDevice 1300 is as follows:

- Install the HelloDevice Utility Software on user's PC
- Connect the HelloDevice to the power supply and Ethernet
- Set the IP address of HelloDevice
- Check the HelloDevice network connection.

4.1 Installing Utility Software

Run **setup1x00.exe** in the HelloDevice CD-ROM from the PC that is connect to the network. **Setup1x00.exe** runs on Microsoft Windows 95/98, NT and 2000. Select [**Complete**] and press [**Next**] button in the setup type display screen.




Figure 4.1. Initial screen of the HelloDevice utility software installation program

The setup program will automatically be installed onto **c:\Program Files\HelloDevice utility** folder.




Figure 4.2. Screen that shows the HelloDevice utility software is being installed

Once setup is completed, a shortcut icon of the HelloDevice Utility Software is created on the desktop and on the program menu. If the following HelloDevice utility main window appears when the shortcut is clicked, the setup has been successfully completed.




Figure 4.3. Initial screen for the HelloDevice utility software

4.2 Connecting Hardware

(1) Connect the 5V power supply adaptor to the HelloDevice.




Figure 4.4. 5V power connection to the HelloDevice

(2) Connect the HelloDevice to the Ethernet hub through the RJ45 connector.

(Refer to the Chapter 3 Main Board Specifications for more details on the RJ45 connector.)




Figure 4.5. Connection of the HelloDevice and Ethernet cable

(3) Check to see if the Tx LED of the HelloDevice Status Display LED blinks periodically in one-second interval. (See the [Status LED] in the Figure 3.1)

4.3 Configuring Network

In order for a HelloDevice to function as a server on the network, a static IP address must be set for the HelloDevice. This section describes how to configure and change IP address for a HelloDevice.

4.3.1 Setting IP Address

The HelloDevice Utility Software is used to set up an IP address for a HelloDevice by utilizing BOOTP (BOOTstrap Protocol), which is defined in the Internet protocol standard, RFC-951 and RFC-1542. The Utility Software provides BOOTP a server function, and will respond to the BOOTP request of the HelloDevice.

Since the factory default setting of the HelloDevice IP address is 0.0.0.0, the HelloDevice sends BOOTP request for IP assignment, when it is powered up for the first time. Thus, users can see Tx LED keeps blinking periodically as a reminder (See Figure 3.1, Status LED).

Since IP address of the HelloDevice is managed by an IP address database, a properly allocated MAC²-IP address record should be entered into the database. For a valid IP address, users should ask their network administrator.




Figure 4.6 IP address setting screen of the HelloDevice utility software

² MAC(Media Access Control) address is total 6 bytes and it is composed of 3 bytes-organization code and 3 bytes-product code. MAC address of HelloDevice is composed of 00-01-95 which is a company code and xx-xx-xx which is a product code. E.g. 00-01-95-01-aa-08

Take the following steps to set up the IP address, using the HelloDevice Utility Software.

Setting an IP address with the HelloDevice Utility Software:

(1) Run the HelloDevice Utility shortcut icon on the desktop of your PC and select [IP Set-up] menu click on the [IP Set-up] window. This window provides the BOOTP server function for IP address setup ([BootP Start], [BootP Stop]), trace function ([IP Find]) and IP address initialize functions ([IP Clear]).

(2) Press the [Add] button and enter the BOOTP database record as shown below.

The image shows a Windows-style dialog box titled "DB Setting for BootP". It contains the following fields and values:

- MAC Type: 1
- MAC Length: 6
- IP: 192 . 168 . 1 . 15
- MAC: 00 : 01 : 95 : 04 : 02 : 03
- Gateway Addr: 192 . 168 . 1 . 1
- Subnet Mask: 255 . 255 . 255 . 0

At the bottom of the dialog are two buttons: "Add" and "Cancel".

Figure 4.7 BOOTP Database Record Input Window

Enter MAC address, IP address of HelloDevice. 1 and 6 should be always entered for H/W address type and H/W address length items for Ethernet. MAC address is printed on the sticker on the Ethernet controller chip of HelloDevice main board. Figure 4.7 shows an example setting of 00:01:95:04:02:03 MAC address and 192.168.1.15 IP address. Since the BOOTP function of HelloDevice is working by using broadcast message, you don't have to enter gateway address and sub net mask.

(3) Click [Add] button to finish database editing.

The records entered in step (2) are added to the IP database.

(4) Launch the functions of BOOTP by pressing the [BootP start] button.

The HelloDevice Utility will then operate as a BOOTP server. Note that the message on the [Status] bar will change from "Monitoring" to "Listening BOOTP request".

If HelloDevice Utility gets BOOTP request from a certain HelloDevice which does not exist in BOOTP DB

List, it will run "DB Setting for BOOTP" window automatically. User should enter IP address and Gateway address of the HelloDevice, and add them to BOOTP DB list.

(5) Check the status of Tx LED on HelloDevice.

The HelloDevice Utility Software will send a reply for IP assignment to the BOOTP request of the HelloDevice. The Tx LED will be blinking periodically to indicate a BOOTP request. At this point, [Status] bar displays the "BootP reply sent... [192.168. 1. 15]" message. Wait until Tx LED does not blink any longer, and then stop the functions of BOOTP server by clicking [BOOTP Stop] button.

(6) Use the ping command to check your IP address setting of HelloDevice.

Run the ping program at the command prompt. If your IP address is correctly set, the response to the ping will be as follows:

```
>> ping 192.168.1.15
```

```
>> Pinging 192.168.1.15 with 32 bytes of data:
```

```
Reply from 192.168.1.15: bytes=32 time=10ms TTL=251
```

```
Reply from 192.168.1.15: bytes=32 time<10ms TTL=251
```

```
Reply from 192.168.1.15: bytes=32 time=10ms TTL=251
```

If the response above is not displayed, the IP address was not entered correctly, so you should repeat steps (4), (5) and (6).

(7) Use [IP Find] to identify IP address setting of HelloDevice.

Click [IP Find] button, and the window in figure 4.8 will be shown. Enter the MAC address of HelloDevice and click [Find] button. The IP address currently set in the "Found IP" item will be displayed.



Figure 4.8 IP address check using the [IP Find] function

(8) Check if the HelloDevice web server operates correctly.

The HelloDevice has a built-in 404.html file in flash memory (factory default). To check the functions of your web server, run any web browser and connect to the address <http://192.168.1.15>. The web page in Figure 4.9 verifies that the HelloDevice works successfully as a web server.




Figure 4.9 HelloDevice default Web page

4.3.2 Changing IP address

To change the IP address, initialize the IP address to the factory default value of 0.0.0.0, and repeat the procedures of setting an IP address in section 4.3.1. At this point, ask your network administrator for a new IP address.

For example, let's try to change IP address of 192.168.1.15 to 192.168.1.18.

(1) Initializing IP address

Before you initialize IP address of HelloDevice, you have to remove IP/MAC address data stored in your PC. This information is stored in ARP cache, and you can make sure what is stored in the cache by using the

following command. This is the response of the command in case that IP address of user PC is 192.168.1.100.

```
>>arp -a
Interface: 192.168.1.100 on Interface 2
Internet Address      Physical Address  Type
192.168.1.15         00-01-95-04-02-03  dynamic
192.168.1.23         01-a0-11-34-11-0d  dynamic
```

Remove the corresponding item to the current HelloDevice information by using the following command.

```
>> arp -d 192.168.1.15
```

Now, you are ready to initialize current IP address of HelloDevice.

Go to [IP Setup] window and click [IP Clear] button to display a window where you can clear the IP address. If you want to clear the current IP address of 192.168.1.15, just enter the current setting of the IP address as shown below in figure 4.10 and click [OK] button. Then, the present IP address of 192.168.1.15 set on HelloDevice will be changed to factory default of 0.0.0.0.




Figure 4.10 IP address Clear window

(2) Verifying the initialization of an IP address

Check if Tx LED of HelloDevice blinks. When an IP address is initialized, the HelloDevice will send the BOOTP request message. The Tx LED of the HelloDevice will keep blinking.

(3) Resetting an IP address

To reset an IP address to 192.168.1.18, edit/modify the contents of the IP address database using the [Edit] function and repeat the procedures of setting an IP address in section 4.3.1.




Figure 4.11 IP address change using the [Edit] function in the IP address database

5. Quick Tour

This chapter describes how to build a homepage on the HelloDevice web server and demonstrates serial communication of the HelloDevice. The following sample program files are included in the Starter Kit.

- 1) First Web server demo sample
- 2) Demo sample of I/O control through the Web
- 3) Java applet source code for I/O demo
- 4) C program source code for I/O demo

In chapter 5.1, we will start the Web server using the sample 1), and test serial communications through the Web using the sample 2). The sample 3) and 4) will be covered in Chapter 6, Connecting User Devices.




Figure 5.1 Location of the HelloDevice Sample Files

5.1 Building a Homepage

For the HelloDevice to function as a web server, web resources like HTML files, image files, and Java class files should be stored on the flash memory of the HelloDevice up to 256 files or a total data size of 500 KByte can be stored on the flash memory.

Since the HelloDevice does not use a general operating systems, web files are managed in the form of “file index table”. Web files are stored in the flash memory of the HelloDevice by **building** an integrated image file and then **uploading** it onto the HelloDevice. This image file contains a file index table that is recognized only by HelloDevice web server. The HelloDevice Utility Software provides the functions of building and uploading this type of file.

To make HelloDevice function as a web server, perform the following steps:

- (1) Create the web pages with a web-publishing tool.
- (2) Use the HelloDevice Utility Software to transform the created web pages into an uploadable form.
- (3) Upload the transformed files to the HelloDevice.
- (4) Use a web browser to connect to the uploaded web page.

In this example, use the web files in the “FirstDemo” folder to construct a web server home page. These examples are composed of: an index.html, HelloDevice block diagram and cube animation demo with a Java applet.

(1) Select [Web files] tab to go to the window containing web file manager tools.




Figure 5.2. Web File Tool screen of the HelloDevice Utility Software

(2) Click [Find] button to find web files to build.

Go to the folder containing the example files, select the top-level “FirstDemo” folder, and click [OK] button.




Figure 5.3. Finding Web server demo files

(3) Select a file name to build.

Enter the file name of the built image and click [Save] button to save. By default the HelloDevice web files built, will have the extension “hd”. The current window closes and “Build complete” dialog box appears.




Figure 5.4. Saving Web sample Build file

(4) Enter an IP address of the HelloDevice to upload the built files.




Figure 5.5. Entering the IP address to upload the built files

(5) Click the [Target file] button to select the built image files to upload.




Figure 5.6. Screen of selecting the Build files to upload

(6) Click [Upload] button to upload the built image files to HelloDevice.

This procedure is displayed on the Progress bar, and when it has finished, a “Flash download completed!” dialog box will appear.

(7) Enter URL <http://192.168.1.15/index.html> in the web browser, and try connecting.

The web page in Figure 5.7 will appear. If not, you might not have entered the value of the IP address correctly and as a result the web server will not operate successfully. If the web page fails to appear, check the IP address setting of web server and reload the file.



Figure 5.7. HelloDevice, “FirstDemo” Web page screen

A user's homepage can be customized in the same way as described above.

5.2 Serial Communication Demo Using Terminal Applet

Sample programs are provided in the HelloDevice 1300 Starter's Kit, for serial communication demo. Let's check the function by using one of the sample programs. You will need a PC equipped with Ethernet card and serial port for Ethernet-to-RS232 data conversion demo.

The scenario is as follows: If you connect to the homepage of the HelloDevice by using any browser, a terminal applet page will be shown to you. If you enter any character by pressing any key on keyboard, the characters will be transferred to the HelloDevice over network. Then, the characters will be transferred to user PC by way of the HelloDevice RS-232 port, if the HelloDevice is hooked up with serial port of user PC. You can see the data stream on your PC by using any RS232 terminal emulator. You may send characters to the network interface of your PC by entering any characters on your RS232 emulator. Take following steps for this demo.

- Configure serial communication parameter of the HelloDevice
- Hook up your PC and the HelloDevice for demo
- Building a Homepage for demo
- Test RS232 communication demo

Conceptual drawing for this demo system is shown in Figure 5.8.




Figure 5.8 Conceptual drawing for the serial communication demo

5.2.1. Configure serial communication parameter of the HelloDevice

the HelloDevice Utility software provides a function to configure serial communication parameter of the HelloDevice serial port to make the parameter as same as that of user device. You can perform this configuration by using the function of [Sys Set-up] window of Utility software.

Take following steps to configure the parameters.

1) **Select [Serial] item from [Device] selection combo box.**

2) **Set the proper item from parameter combo box.**

- baud rate
One of 150, 300, 600, 900, 1200, 2000, 2400, 3600, 4800, 7200, 9600, 19200, 38400
- parity
One of None, Even, Odd
- Data bits
One of 5, 6, 7, 8 bits
- Stop bits
One of 1, 1 ½ 2 bit
- handshake
One of None, H/W, X On/Off

Let's say that IP address of the HelloDevice is 192.168.1.15, and the serial communication parameters are 9600 baud rate, Parity None, Data bit 8, Stop bit 1 and Handshake None.




Figure 5.9 Serial parameter input window

- 3) Press [Send] button and these parameters will be sent to the HelloDevice via network. the HelloDevice will set its serial communication parameter as such.

5.2.2 Hook up your PC and the HelloDevice for demo

Take following steps to properly hook up the demo components.

- 1) Prepare a PC connected to network.
- 2) Hook up RS232 cable between the RS232 port of your PC and that of the HelloDevice. You can refer to the cable specification at chapter 3.
- 3) Run RS232 terminal emulator on your PC.

We will show this demo by using HyperTerminal program of your PC. Let's say you are using COM1 port for serial communication demo.
- 4) Set the parameters of **HyperTerminal** program.

Set the parameters as same as those of the HelloDevice serial port, as you finished in chapter 5.2.1.




Figure 5.10 RS232 parameter of HyperTerminal

5) Run **HyperTerminal** by press [OK] button.

5.2.3 Building a Homepage for Demo

Use sample web files of the HelloDevice Utility Software in “Demo\SerialDemo” folder to test RS232 communication of the HelloDevice (See Figure 5.1 for the location of the sample files). index.html, terminal.jar and 404.html files in the folder are used.

(1) Modify index.html file in “SerialDemo” folder.

Enter IP address of the HelloDevice currently in the IP address parameter associated with Java applet within index.html file. Save the file without modifying other parameters.

```
<HTML>
<HEAD>
<TITLE>telnet</TITLE>
</HEAD>
<BODY>
<H1>telnet</H1>
<APPLET CODE=telnet.class ARCHIVE=serial.jar WIDTH=590 HEIGHT=190>
<param name=address value="192.168.1.15">
<param name=port value=6001>
<param name=emulation value=vt320>
<param name=VTcolumns value=40>
<param name=VTrows value=12>
<param name=VTfont value=Courier>
<param name=VTfontsize value=24>
<param name=VTbuffer value=8>
<param name=VTscrollbar value=true>
<param name=VTcharset value=ibm>
</APPLET>
</BODY>
</HTML>
```

Figure 5.11 index.html file for RS232 communication demo

(2) Build and upload web files in “SerialDemo” folder.

Follow the procedure described in section 5.1 with web files in “SerialDemo” folder instead of “FirstDemo” folder to upload these web pages to the HelloDevice.

(3) After uploading has been completed, run the web browser to go to <http://192.168.1.15/index.html> page.

If the web page in figure 5.12 is not displayed, retry the (2) procedure.

(4) Test serial communication functionality of the HelloDevice.

You can try to test communication between your PC and HelloDevice in bi-directional manner. If you enter characters on terminal applet of the HelloDevice web site, they are eventually echoed to the window of HyperTerminal, or vice versa. In this demo, your PC functions both as a user device and as a user PC for remote control of user device.




Figure 5.12 Ethernet/Serial conversion demo between the HelloDevice and user PC

While "A" is communicating with user device thru HelloDevice, HelloDevice disregards connection request from "B". This is because RS-232C Serial communication only supports 1:1 communication.

After a few seconds (8 seconds) have passed without data transmission between HelloDevice and the remote user, HelloDevice disconnects current socket communication and waits for another connection request.

6. Connecting User Devices

In order to communicate with your device connected to the HelloDevice 1300 from your PC, you should implement an Internet socket program on your PC. It should send an ASCII string to the HelloDevice by TCP/IP protocol. When the HelloDevice receives the string, it will pass the string to its serial port. Finally, the string is transmitted to the serial port of the user device, if it is hooked up with the HelloDevice, or vice versa.

Figure 6.1 shows a basic concept of remote data communication by using the HelloDevice. You should implement an Internet socket program or Java applet based on the HelloDevice communication protocol. You should also hook up the user device according to the specification of the HelloDevice serial port.




Figure 6.1 Remote serial communication of the HelloDevice

6.1 Connecting Hardware

Only one of RS232 or RS485 communication mode is supported in the HelloDevice serial port. You can configure the communication mode, by sliding the RS232/485 mode conversion switch on the main board. Serial cable connection is changed due to the communication mode. Figure 6.2 shows the communication mode configuration by using SW2, RS232/485 conversion switch.




Figure 6.2 RS232/485 communication mode switching

6.1.1 RS232 communication

Only 4 pins of RxD, TxD, RTS, and CTS are used in RS232 communication of the HelloDevice. You have to make RS232 communication cable by using the connection shown in Figure 6.3.




Figure 6.3 RS232 communication cable connection diagram

6.1.2 RS485 communication

Only 2 pins of RS485+ and RS485- are used in RS485 communication of the HelloDevice. You have to make RS485 communication cable by using the connection shown in Figure 6.4.




Figure 6.4 RS485 communication cable connection diagram

6.2 Sample programs

The Internet socket interface should be implemented either by socket application or by Java applet. The stream's target TCP port of the HelloDevice is 6001. Then, the HelloDevice will just pass the data to user device by serial protocol.

6.2.1 Implementing Socket program

The following C program source code shows how to implement Internet socket interface program for the HelloDevice communication. This sample code is implemented to send ASCII string data to the HelloDevice, by using Berkeley socket C API functions. This source is a part of the entire source code "the HelloDevice installation folder\Src\SerialDemo\C\serialdemo.c".

```

//-----
// Process Serial data send
//-----
void SerialSend()
{
    char commandBuf[512]="";
    int    commandLen ;
    int    err ;

    // Re-Initialize TCP socket
    TCPSocketInit() ;

    // Read serial data
    // : just ASCII string excluding control characters...
    // : Max size is limited to 512 bytes in this demo...
    printf("\nEnter serial data:");
    scanf("%s", commandBuf) ;

    // Calc serial data length
    commandLen = strlen(commandBuf) ;

    // Send command to the HelloDevice
    err = sendto
        (
            sock,
            &commandBuf,
            commandLen,
            0,
            (struct sockaddr*)&clientAddr,
            sizeof(clientAddr)
        ) ;
    if (err == -1 )
    {
        perror("\nsend error\n");
        exit (1);
    }
}

```


6.2.2 Implementing Java applet

Program source for terminal applet is located in “the HelloDevice Install folder\Src\SerialDemo\java” folder. The source code is from public domain free source, “telnet java applet”. We modified the code so that it may work with the HelloDevice. Further information on “telnet java applet” can be found in the folder of “1300_telnet_documentation” of the HelloDevice install CDROM.

Appendix A. IP address configuration by using cross-over Ethernet cable


You may configure the wrong IP address for the HelloDevice that cannot be run in your current network environment. You might not initialize the IP address of the HelloDevice before you install it to different network environment. In these cases, you cannot access the HelloDevice via network, since only network-based IP configuration function is provided in the HelloDevice.

In these cases, you will have to use crossover Ethernet cable for communication with the HelloDevice. The ordinary Ethernet cable is straight type, in which Rx line is connected into Rx line of other side and Tx line with Tx line of other side. Meanwhile, crossover Ethernet cable is a cable with Rx connected to Tx of the other side, and Tx to Rx of the other side.




You can emulate the 1:1 networking if you hook up crossover cable between your PC and the HelloDevice, without being affected by network routing. Take following steps for IP address reconfiguration.

- 1) Remove Ethernet cable from your PC
- 2) Directly hook up crossover cable between your PC and the HelloDevice



- 3) Configure the network environment set-up of your PC so that it can communicate with the HelloDevice. TCP/IP parameters of network configuration should be modified temporarily.

e.g. Let's say that IP address of the HelloDevice is 192.168.1.23 and that of your PC is 172.168.1.22. Modify the IP address of your PC and gateway as shown in the following picture.



You may modify the IP address to different IP address of 192.168.1.xx other than 192.168.1.23, since those addresses can also be working in the subnet. Then, press [OK] button. You will have to keep in mind your original network environment set-up parameters, since this is temporary set-up for IP address reconfiguration of the HelloDevice.

- 4) Make sure if your PC can communicate with the HelloDevice by using ping utility

```
>> ping 192.168.1.23
>> Pinging 192.168.1.23 with 32 bytes of data:
    Reply from 192.168.1.23: bytes=32 time=10ms TTL=251
    Reply from 192.168.1.23: bytes=32 time<10ms TTL=251
    Reply from 192.168.1.23: bytes=32 time=10ms TTL=251
```

- 5) Run the HelloDevice Utility program
- 6) Take steps described in chapter 4.3.2, "Changing IP address"